



Assembly and Operating Manual

SRU-plus-D

Pneumatic swivel unit

Original Operating Manual

Hand in hand for tomorrow

Imprint

Copyright:

This manual is protected by copyright. The author is SCHUNK SE & Co. KG.
All rights reserved.

Technical changes:

We reserve the right to make alterations for the purpose of technical improvement.

Document number: 1380765

Version: 06.00 | 23/10/2023 | en

Dear Customer,

Thank you for trusting our products and our family-owned company, the leading technology supplier of robots and production machines.

Our team is always available to answer any questions on this product and other solutions. Ask us questions and challenge us. We will find a solution!

Best regards,

Your SCHUNK team

Customer Management

Tel. +49-7133-103-2503

Fax +49-7133-103-2189

cmg@de.schunk.com



Please read the operating manual in full and keep it close to the product.

Table of Contents

1 General	6
1.1 About this manual.....	6
1.1.1 Presentation of Warning Labels	6
1.1.2 Applicable documents	6
1.1.3 Sizes.....	7
1.1.4 Variants	7
1.2 Warranty	8
1.3 Scope of delivery.....	8
1.3.1 Accessories pack.....	8
1.4 Accessories	10
1.4.1 Seal kit	10
2 Basic safety notes	12
2.1 Intended use.....	12
2.2 Not intended use	12
2.3 Constructional changes.....	12
2.4 Spare parts	12
2.5 Ambient conditions and operating conditions	12
2.6 Personnel qualification	13
2.7 Personal protective equipment	14
2.8 Notes on safe operation.....	14
2.9 Transport.....	14
2.10 Malfunctions	15
2.11 Disposal	15
2.12 Fundamental dangers	15
2.12.1 Protection during handling and assembly	15
2.12.2 Protection during commissioning and operation	16
2.12.3 Protection against dangerous movements	16
2.12.4 Protection against electric shock.....	17
2.13 Notes on particular risks	17
3 Technical data	19
3.1 Type key.....	19
3.2 Basic data	20
4 Design and description	21
4.1 Design	21
4.1.1 Variant with electrical feed-through (EDF)	22
4.2 Description	23

5 Assembly.....	24
5.1 Assembling and connecting.....	24
5.2 Connections	26
5.2.1 Mechanical connection.....	26
5.2.2 Pneumatic connection.....	29
5.2.3 Electrical connection	31
5.3 Mounting separating sleeve.....	33
5.4 Settings.....	33
5.4.1 Adjust swivel angle.....	35
5.4.2 Adjust swiveling speed	37
5.4.3 Adjust absorber stroke.....	39
5.4.4 Set center position	40
5.4.5 Set locked center position	41
5.5 Mounting inductive proximity switch IN 80	42
6 Start-up	43
6.1 Setting ranges of the variants	43
6.2 Base unit.....	43
6.3 Center position	43
6.4 Locked center position	45
6.5 Locked center position with separate piston chambers	47
7 Troubleshooting.....	49
7.1 Product does not move smoothly to the end positions	49
7.2 Product does not travel through the rotating angle	49
7.3 Product rotates jerkily	49
7.4 Product does not move.....	49
7.5 Torque is diminishing	50
8 Maintenance	51
8.1 Maintenance interval.....	51
8.2 Lubricants/Lubrication points (basic lubrication)	52
8.3 Inspect and set shock absorbers	53
8.3.1 Inspect shock absorbers.....	53
8.3.2 Set shock absorber overhang	53
8.3.3 Shock absorber types and overlap	54
8.4 Servicing shock absorber.....	55
8.5 Replace shock absorber	56
8.5.1 Replace shock absorber (base unit)	56
8.5.2 Replacing external shock absorber (locked center position)	57
8.5.3 Replace internal shock absorber (locked center position)	57

8.6 Disassembly and assembly	59
8.6.1 Dismantling and assembling rotary actuator (base unit)	59
8.6.2 Dismantle and assemble rotary actuator (center position/locked center position)	60
8.6.3 Dismantling and assembling rotary actuator (fluid feed-through).....	61
9 UKCA declaration of incorporation	62
10 Translation of the original declaration of incorporation	63
11 UKCA declaration of incorporation	64
12 Information on the RoHS Directive, REACH Regulation and Substances of Very High Concern (SVHC)	65

1 General

1.1 About this manual

This manual contains important information for a safe and appropriate use of the product.

This manual is an integral part of the product and must be kept accessible for the personnel at all times.

Before starting work, the personnel must have read and understood this operating manual. Prerequisite for safe working is the observance of all safety instructions in this manual.

In addition to these instructions, the documents listed under ► 1.1.2 [6] are applicable.

NOTE: The illustrations in this manual are intended to provide a basic understanding and may deviate from the actual version.

1.1.1 Presentation of Warning Labels

To make risks clear, the following signal words and symbols are used for safety notes.



⚠ DANGER

Dangers for persons!

Non-observance will inevitably cause irreversible injury or death.



⚠ WARNING

Dangers for persons!

Non-observance can lead to irreversible injury and even death.



⚠ CAUTION

Dangers for persons!

Non-observance can cause minor injuries.

CAUTION

Material damage!

Information about avoiding material damage.

1.1.2 Applicable documents

- General terms of business *
- Catalog data sheet of the purchased product *

The documents labeled with an asterisk (*) can be downloaded from [schunk.com](https://www.schunk.com).

1.1.3 Sizes

This operating manual applies to the following sizes:

- SRU-plus-D 20
- SRU-plus-D 25
- SRU-plus-D 30
- SRU-plus-D 35
- SRU-plus-D 40
- SRU-plus-D 50
- SRU-plus-D 60

1.1.4 Variants

This operating manual applies to the following variations:

- SRU-plus-D Rotating angle 90°
- SRU-plus-D Rotating angle 180°
- SRU-plus-D End position adjustability 3°
- SRU-plus-D with fluid feed-through
- SRU-plus-D With pneumatic center positioning (M)
- SRU-plus-D With locked center position (VM)
- SRU-plus-D With electrical feed-through (EDF)

1.2 Warranty

If the product is used as intended, the warranty is valid for 24 months from the ex-works delivery date under the following conditions:

- Observe the specified maintenance and lubrication intervals
- Observe the ambient conditions and operating conditions

Parts touching the workpiece and wear parts are not included in the warranty.

1.3 Scope of delivery

The scope of delivery includes

- Pneumatic swivel unit SRU-plus-D in the version ordered
- Assembly and Operating Manual
- Accessory pack

1.3.1 Accessories pack

SRU-plus-D	ID number
without fluid feed-through	
20	5514981
25	5514981
30	5518653
35	5514989
40	5514993
50	5514997
60	5515001
with fluid feed-through	
20	5514982
25	5514982
30	5518654
35	5514990
40	5514994
50	5514998
60	5515002
with center position	
20	5516590
25	5516590
30	5518657
35	5516594
40	5516596

SRU-plus-D	ID number
50	5516598
60	5516600
with locked center position	
20	5514983
25	5514983
30	5518655
35	5514991
40	5514995
50	5514999
60	5515003
with fluid feed-through and center position	
20	5516591
25	5516591
30	5518658
35	5516595
40	5516597
50	5516599
60	5516601
with fluid feed-through and locked center position	
20	5514984
25	5514984
30	5518656
35	5514992
40	5514996
50	5515000
60	5515004

1.4 Accessories

A wide range of accessories are available for this product
For information regarding which accessory articles can be used
with the corresponding product variants, see catalog data sheet.

1.4.1 Seal kit

SRU-plus-D	ID number
Basic sealing kit	
20	0371000
25	0371004
30	5518598
35	0371008
40	0371012
50	0371016
60	0371020
with center position	
20	5519788
25	5519792
30	5519798
35	5519800
40	5519804
50	5519808
60	5519812
with locked center position	
20	5519789
25	5519793
30	5519799
35	5519801
40	5519805
50	5519809
60	5519813
with fluid feed-through	
20	0371003
25	0371007
30	5518599
35	0371011
40	0371015
50	0371019

SRU-plus-D	ID number
60	0371023
with fluid feed-through and center position	
20	5519790
25	5519794
30	5519796
35	5519802
40	5519806
50	5519810
60	5519814
with fluid feed-through and locked center position	
20	5519791
25	5519795
30	5519797
35	5519803
40	5519807
50	5519811
60	5519815
SRU-plus-D	ID number
Basic sealing kit	
20	5521583
25	5521583
30	5521585
35	5521587
40	5521589
50	5521591
60	5521591
Basic sealing kit + monitoring set	
20	5521584
25	5521584
30	5521586
35	5521588
40	5521590
50	5521592
60	5521592

with EDF

2 Basic safety notes

2.1 Intended use

The product may only be used for swiveling permissible attachment parts or workpieces.

- The product may only be used within the scope of its technical data, ► 3 [19].
- When implementing and operating components in safety-related parts of the control systems, the basic safety principles in accordance with DIN EN ISO 13849-2 apply. The proven safety principles in accordance with DIN EN ISO 13849-2 also apply to categories 1, 2, 3 and 4.
- The product is intended for installation in a machine/ automated system. The applicable guidelines for the machine/ automated system must be observed and complied with.
- The product is intended for industrial and industry-oriented use.
- Appropriate use of the product includes compliance with all instructions in this manual.

2.2 Not intended use

Inappropriate use includes using the product as a cutting tool or drilling tool, for example.

- Any utilization that exceeds or differs from the appropriate use is regarded as misuse.

2.3 Constructional changes

Implementation of structural changes

Modifications, changes or reworking, e.g. additional threads, holes, or safety devices, can damage the product or impair its functionality or safety.

- Structural changes should only be made with the written approval of SCHUNK.

2.4 Spare parts

Use of unauthorized spare parts

Using unauthorized spare parts can endanger personnel and damage the product or cause it to malfunction.

- Use only original spare parts or spares authorized by SCHUNK.

2.5 Ambient conditions and operating conditions

Required ambient conditions and operating conditions

Incorrect ambient and operating conditions can make the product unsafe, leading to the risk of serious injuries, considerable material damage and/or a significant reduction to the product's life span.

- Make sure that the product is used only in the context of its defined application parameters, ► 3 [19].
- Make sure that the product is a sufficient size for the application.
- Make sure that the environment is free from splash water and vapors as well as from abrasion or processing dust. Exceptions are products that are designed especially for contaminated environments.

2.6 Personnel qualification

Inadequate qualifications of the personnel

If the personnel working with the product is not sufficiently qualified, the result may be serious injuries and significant property damage.

- All work may only be performed by qualified personnel.
- Before working with the product, the personnel must have read and understood the complete assembly and operating manual.
- Observe the national safety regulations and rules and general safety instructions.

The following personal qualifications are necessary for the various activities related to the product:

Trained electrician	Due to their technical training, knowledge and experience, trained electricians are able to work on electrical systems, recognize and avoid possible dangers and know the relevant standards and regulations.
Qualified personnel	Due to its technical training, knowledge and experience, qualified personnel is able to perform the delegated tasks, recognize and avoid possible dangers and knows the relevant standards and regulations.
Instructed person	Instructed persons were instructed by the operator about the delegated tasks and possible dangers due to improper behaviour.
Service personnel of the manufacturer	Due to its technical training, knowledge and experience, service personnel of the manufacturer is able to perform the delegated tasks and to recognize and avoid possible dangers.

2.7 Personal protective equipment

Use of personal protective equipment

Personal protective equipment serves to protect staff against danger which may interfere with their health or safety at work.

- When working on and with the product, observe the occupational health and safety regulations and wear the required personal protective equipment.
- Observe the valid safety and accident prevention regulations.
- Wear protective gloves to guard against sharp edges and corners or rough surfaces.
- Wear heat-resistant protective gloves when handling hot surfaces.
- Wear protective gloves and safety goggles when handling hazardous substances.
- Wear close-fitting protective clothing and also wear long hair in a hairnet when dealing with moving components.

2.8 Notes on safe operation

Incorrect handling of the personnel

Incorrect handling and assembly may impair the product's safety and cause serious injuries and considerable material damage.

- Avoid any manner of working that may interfere with the function and operational safety of the product.
- Use the product as intended.
- Observe the safety notes and assembly instructions.
- Do not expose the product to any corrosive media. This does not apply to products that are designed for special environments.
- Eliminate any malfunction immediately.
- Observe the care and maintenance instructions.
- Observe the current safety, accident prevention and environmental protection regulations regarding the product's application field.

2.9 Transport

Handling during transport

Incorrect handling during transport may impair the product's safety and cause serious injuries and considerable material damage.

- When handling heavy weights, use lifting equipment to lift the product and transport it by appropriate means.

- Secure the product against falling during transportation and handling.
- Stand clear of suspended loads.

2.10 Malfunctions

Behavior in case of malfunctions

- Immediately remove the product from operation and report the malfunction to the responsible departments/persons.
- Order appropriately trained personnel to rectify the malfunction.
- Do not recommission the product until the malfunction has been rectified.
- Test the product after a malfunction to establish whether it still functions properly and no increased risks have arisen.

2.11 Disposal

Handling of disposal

The incorrect handling of disposal may impair the product's safety and cause serious injuries as well as considerable material and environmental harm.

- Follow local regulations on dispatching product components for recycling or proper disposal.

2.12 Fundamental dangers

General

- Observe safety distances.
- Never deactivate safety devices.
- Before commissioning the product, take appropriate protective measures to secure the danger zone.
- Disconnect power sources before installation, modification, maintenance, or calibration. Ensure that no residual energy remains in the system.
- If the energy supply is connected, do not move any parts by hand.
- Do not reach into the open mechanism or movement area of the product during operation.

2.12.1 Protection during handling and assembly

Incorrect handling and assembly

Incorrect handling and assembly may impair the product's safety and cause serious injuries and considerable material damage.

- Have all work carried out by appropriately qualified personnel.
- For all work, secure the product against accidental operation.
- Observe the relevant accident prevention rules.
- Use suitable assembly and transport equipment and take precautions to prevent jamming and crushing.

Incorrect lifting of loads

Falling loads may cause serious injuries and even death.

- Stand clear of suspended loads and do not step into their swiveling range.
- Never move loads without supervision.
- Do not leave suspended loads unattended.

2.12.2 Protection during commissioning and operation

Falling or violently ejected components

Falling and violently ejected components can cause serious injuries and even death.

- Take appropriate protective measures to secure the danger zone.
- Never step into the danger zone during operation.

2.12.3 Protection against dangerous movements

Unexpected movements

Residual energy in the system may cause serious injuries while working with the product.

- Switch off the energy supply, ensure that no residual energy remains and secure against inadvertent reactivation.
- Never rely solely on the response of the monitoring function to avert danger. Until the installed monitors become effective, it must be assumed that the drive movement is faulty, with its action being dependent on the control unit and the current operating condition of the drive. Perform maintenance work, modifications, and attachments outside the danger zone defined by the movement range.
- To avoid accidents and/or material damage, human access to the movement range of the machine must be restricted. Limit/prevent accidental access for people in this area due through technical safety measures. The protective cover and protective fence must be rigid enough to withstand the maximum possible movement energy. EMERGENCY STOP switches must be easily and quickly accessible. Before starting up the machine

or automated system, check that the EMERGENCY STOP system is working. Prevent operation of the machine if this protective equipment does not function correctly.

2.12.4 Protection against electric shock

Possible electrostatic energy

Components or assembly groups may become electrostatically charged. When the electrostatic charge is touched, the discharge may trigger a shock reaction leading to injuries.

- The operator must ensure that all components and assembly groups are included in the local potential equalisation in accordance with the applicable regulations.
- While paying attention to the actual conditions of the working environment, the potential equalisation must be implemented by a specialist electrician according to the applicable regulations.
- The effectiveness of the potential equalisation must be verified by executing regular safety measurements.

2.13 Notes on particular risks



DANGER

Risk of fatal injury from suspended loads!

Falling loads can cause serious injuries and even death.

- Stand clear of suspended loads and do not step within their swiveling range.
- Never move loads without supervision.
- Do not leave suspended loads unattended.
- Wear suitable protective equipment.



WARNING

Risk of injury from objects falling and being ejected!

Falling and ejected objects during operation can lead to serious injury or death.

- Take appropriate protective measures to secure the danger zone.



⚠ WARNING

Risk of injury due to unexpected movements!

If the power supply is switched on or residual energy remains in the system, components can move unexpectedly and cause serious injuries.

- Before starting any work on the product: Switch off the power supply and secure against restarting.
- Make sure, that no residual energy remains in the system.



⚠ WARNING

Risk of injury from sharp edges and corners!

Sharp edges and corners can cause cuts.

- Use suitable protective equipment.



⚠ WARNING

Risk of burns through contact with hot surfaces!

Surfaces of components can heat up severely during operation. Skin contact with hot surfaces causes severe burns to the skin.

- For all work in the vicinity of hot surfaces, wear safety gloves.
- Before carrying out any work, make sure that all surfaces have cooled down to the ambient temperature.



⚠ WARNING

Risk of injury from parts coming loose!

If the shock absorbers are faulty, the product can become damaged. Parts coming loose in this way can lead to injuries.

- Regularly check the components for wear and damage.



⚠ WARNING

Risk of injury if the condition or behavior of the product is undefined!

Cutting off the compressed air supply in an uncontrolled manner could lead to undefined states and behavior. This may cause personal injury or material damage.

- The operator must define suitable emergency stop and restarting strategies.
 - ⇒ Emergency stop strategies: e.g. by means of controlled shut down
 - ⇒ Restarting strategies: e.g. using pressure build-up valves or suitable valve switching sequences

3 Technical data

3.1 Type key

SRU-plus-D 20 - W-180 - 3 - M - 4 - M8 - AS	
Size	
20 25 30	
35 40 50	
60	
Type of damping method	
W = Soft	
Angle of rotation	
90°	
180°	
End position adjustability	
3°	
Center position	
– = none	
M = pneumatic	
VM = locked	
Fluid feed-through	
– = none	
4 = 4 channels for sizes 20 – 35	
8 = 8 channels for sizes 40 – 60	
Electrical feed-through	
– = none	
M8 = M8 connector on the rotating side	
M12 = M12 connector on the rotating side	
Mounting kit for inductive proximity switch	
AS	

Type key

3.2 Basic data

Designation	Value
Noise emission [dB(A)]	≤70
Pressure medium	Compressed air, compressed air quality according to ISO 8573-1:2010 [7:4:4]
Min. pressure [bar]	4
Max. pressure [bar]	8
Max. pressure [bar] (Variant with locked center position)	6.5

Tab.: Basic data

EDF

Designation	Value
Max. voltage [V]	24
Max. current per wire [A]	1
Maximum transmission rate Profibus [MBaud]	1.5

Tab.: Basic data EDF


The catalog data sheet contains diagrams for designing the maximum permissible mass moment of inertia.

The SCHUNK contact person provides support for designing further applications.

More technical data is included in the catalog data sheet.
Whichever is the latest version.

4 Design and description


4.1 Design



Structure

1	Housing	9	Flange for fluid feed-through
2	Back stops (0° – 180°)	10	Pinion for fluid feed-through
3	Back stops (0° – 90°)	12	Monitoring with fixed cam
4	Pinion	13	Sensor holder with sensor
5	Pistons with shock absorbers	14	Attaching center position (0°–90°–180°)
6	Cover	15	Back stops locked center position
7	Cover	16	Pistons with shock absorbers for locked center position
8	Clamp shells	17	Attaching locked center position (0°–90°–180°)

4.1.1 Variant with electrical feed-through (EDF)



Assembly with EDF (SRU-plus-D1 50 displayed)

- | | |
|---|-----------------------------------|
| 1 | Base unit with fluid feed-through |
| 2 | Sensor holder with sensor |
| 3 | Monitoring with fixed cam |
| 4 | EDF flange |
| 5 | Distributor plate |

4.2 Description

The product is a pneumatic rotary actuator for rotating and swiveling movements.

The following designs are possible for the product:

Angle of rotation

Depending on the variant, an angle of rotation of 180° or 90° is possible for the product.

End positions

The end positions can be configured from +3°/-3°.

Variant center position (M), locked center position (VM)

The center position variant allows you to switch between pneumatic and locked. The locked center position can be unlocked when loaded.

Fluid feed-through (MDF) variant

With the fluid feed-through variant, gasses, fluids and vacuums can be fed through without hoses.

Electrical feed-through (EDF) variant

With the electrical feed-through (EDF) variant, signals for supplying the product can be carried out with operational safety.

Note: The electrical rotary feed-through (EDF) variant is only possible in combination with the fluid feed-through (MDF) variant.

5 Assembly

5.1 Assembling and connecting



⚠ WARNING

Risk of injury due to unexpected movement of the machine/system!

With a horizontal swiveling axis, secure locking is not guaranteed during the ventilation stage when a swivelling movement is being performed from 3 o'clock (180°) to 6 o'clock (90°) or from 9 o'clock (0°) to 6 o'clock (90°).

- Screw the separating sleeves into air connections "A" and "B".
- Control both piston chambers of the "A" and "B" air connections separately for the purpose of holding torque.

CAUTION

Risk of damage to the product!

If the end position is approached too hard, the product may be damaged.

- As a rule, a rotary movement must take place without impact and bouncing.
- To do this, carry out sufficient throttle and dampening.
- Observe specifications in the catalog data sheet.

CAUTION

Material damage due to opened exhaust air throttle valves!

If during first actuation the exhaust throttle valves are open, the product may move in an uncontrolled manner.

- Close the exhaust air throttle valves completely before applying pressure.

1. Screw on rotary actuator, ► 5.2.1 [26].
 - ⇒ Zentrierhülsen verwenden.
 - ⇒ Anzugsdrehmoment der Befestigungsschrauben beachten.
2. Screw attachment on the pinion with two fitting screws and two mounting screws, ► 5.2.1 [26].
3. In air connections "A" and "B", screw in throttle valves and connect compressed air lines.

Or with hose-free direct connection:

Screw locking screws into air connections "A" and "B", ► 5.2.2 [29].

Mount throttle valves in the supply lines "a" and "b".

4. Screw in locking screws in open and not required air connections where appropriate.
5. With the variant with electrical feed-through (EDF), connect connection cable, ► 5.2.3 [31].
6. For application cases with horizontal swivel axes, mount separating sleeves, ► 5.3 [33].
7. Adjust angle of rotation, ► 5.4.1 [35].
8. Adjust swiveling speed, ► 5.4.2 [37].
9. Adjust absorber stroke, ► 5.4.3 [39].
10. Mount sensor if necessary, ► 5.5 [42].

5.2 Connections

5.2.1 Mechanical connection

NOTE


Adapter plates between the product and the machine/system as well as the product and the attachment part must be made of high-strength aluminum or steel. The tolerance class for the fitting bore is H7.

Connections on housing

The product can be assembled from two sides.

- On the attachment side via through-bores
- On the side of the apparatus via threaded holes

Centering sleeves for the mounting screws are included in the accessory pack.




Assembly options

SRU-plus-D	① Centering sleeve	② Screws *
20	Ø12	M8 / 24
25	Ø12	M8 / 24
30	Ø12	M8 / 24
35	Ø12	M8 / 24
40	Ø14	M10 / 25
50	Ø16	M12 / 25
60	Ø16	M12 / 25

* Thread / max. depth of engagement from locating surface [mm]


Attachment connections without fluid feed-through




Attachment connection without fluid feed-through

Item	Designation	SRU-plus-D						
		20	25	30	35	40	50	60
1	Threads for mounting screws	M5	M6	M6	M6	M8	M10	M10
	Max. depth of engagement from locating surface [mm]	9	10	9	10	9	15	15
2	Centering sleeve	Ø6	Ø6	Ø6	Ø6	Ø8	Ø10	Ø10

Attachment connections with fluid feed-through



Attachment connection with fluid feed-through up to size 30, example size 25




Attachment connection with fluid feed-through from size 35, example size 50

Item	Designation	SRU-plus-D						
		20	25	30	35	40	50	60
1	Threads for mounting screws	M5	M5	M5	M6	M8	M10	M10
	Max. depth of engagement from locating surface [mm]	9	9	9	10	9	15	15
2	Threads for mounting screws	M5	M5	M5	M5	M6	M8	M8

Item	Designation	SRU-plus-D						
		20	25	30	35	40	50	60
	Max. depth of engagement from locating surface [mm]	9.5	9	9	9	11	13	13
3	Centering sleeve	Ø8	Ø8	Ø8	Ø6	Ø8	Ø10	Ø10

5.2.1.1 Variant with electrical feed-through (EDF)

With the variant with electrical feed-through (EDF), it can only be assembled on the side of the apparatus via the threaded hole.




Assembly options

- | | | | |
|---|---|---|--------------------------|
| 1 | Threaded holes assembly on the apparatus side | 2 | Customer's adapter plate |
|---|---|---|--------------------------|

Attachment connection

If the hose-free direct connection is used, the set-screws must be removed.

With the variant with electrical feed-through (EDF), assembly of the attachment with fitting screws is not possible.



Attachment connection


1 Set-screw

2 Side air connection

5.2.2 Pneumatic connection

NOTE

- Observe the requirements for the compressed air supply, ► 3 [19].
- In case of compressed air loss (cutting off the energy line), the product loses its dynamic effects and does not remain in a secure position. However, the use of a SDV-P pressure maintenance valve is recommended in this case in order to maintain the dynamic effect for some time.



Air connections, variant with center position

Designation	Function
Hose-free direct connection	
a	Swiveling 0° - 90° / 0° - 180°

Designation	Function
b	Swiveling 90° – 0° / 180° – 0°
c	Approach center position (M)
d	Extend locking position (VM)
Hose connection	
A	Swiveling 0° – 90° / 0° – 180°
B	Swiveling 90° – 0° / 180° – 0°
C	Approach center position (M)
D	Extend locking position (VM)

- Only open the air connections required.
- Seal those main air connections that are not needed using the locking screws from the accessory pack.
- For hose-free direct connections, use the O-rings from the accessory pack.
- Use throttle valve from the accessory pack for the main air connections.
- With hose-free direct connections, throttle valves must be fitted in front of the main air connections.

Pay attention to the following table when using throttle valves.

Variant	Air connection					
	A		B		C	D
without center position	Exhaust		Exhaust		–	–
With center position (M)	Exhaust		Exhaustt		Suppl y air	Suppl y air
With locked center position (VM)	Zuluft		Zuluft		Suppl y air	Suppl y air
With locked center position (VM) and separate piston chambers	A1 Exhau st	A2 Suppl y air	B1 Exhau st	B2 Suppl y air	Suppl y air	Suppl y air

Variant with center position (M)

Variant with locked center position (VM)

For the pneumatic center position, the air connections *C* and *D* must be actuated together with a branching.

If supply air throttle valves are used with the locked center position on the air connections *C* and *D*, the locking is engaged smoothly. The operating pressure for the lock must be between 4 and 6 bar.

If exhaust throttle valves are used on the variant with locked center position, this can cause malfunctions.

Variant with fluid feed-through


The connections marked with numbers on the pinion and the flange are provided for feed-through of vacuum, gasses or fluids.

5.2.3 Electrical connection


Bending radius

Minimum bending radius for constant movement: 10 x cable diameter

Size 20-35



SRU-plus-D with EDF, example SRU-plus-D 30




Pin assignment Sleeve1 to 4, Connector A, B


Pin	Pin allocation	
	Connector A	Connector B
1	+24 VDC	+24 VDC
2	Socket 1, Pin 4	Socket 2, Pin 4
3	GND	GND
4	Socket 4, Pin 4	Socket 3, Pin 4

Tab.: Pin allocation SRU-plus-D 20-35

Size 40-60



SRU-plus-D with EDF, example SRU-plus-D1 50



Pin assignment Sleeve 1 to 9, Connector C, D, E

Pin	Pin allocation		
	Connector C	Connector D	Connector E
1	+24 VDC	+24 VDC	+24 VDC
2	Socket 9, Pin 2	Socket 2, Pin 4	Socket 6, Pin 4
3	GND	GND	GND
4	Socket 9, Pin 4	Socket 1, Pin 4	Socket 5, Pin 4
5	-	Socket 3, Pin 4	Socket 7, Pin 4
6	-	Socket 4, Pin 4	Socket 8, Pin 4
7	-	not occupied	not occupied
8	-	not occupied	not occupied

Tab.: Pin allocation SRU-plus-D1 40-60


5.3 Mounting separating sleeve

CAUTION

The O-ring could be damaged!

If the set-screw is turned too far into the air connection, the O-ring may be damaged when screwing in the separating sleeve and the air connection may not be sealed tightly.

- Unscrew the set-screw slightly.
- Screw the separating sleeve carefully until the end of the threads.



1. On the apparatus side (1), unscrew the locking screws (3) out of the air connections A and B.
2. Unscrew the set-screws (4) slightly.
3. Screw separating sleeves (2) from the accessory kit into the air connections A and B up to the end of the threads.
4. Screw in unscrewed set-screws (4) up to the separating sleeve.
5. Mount hose connections A1, A2, B1 and B2.
⇒ Position the hose connections, ► 5.2.2 [29].

5.4 Settings

CAUTION

Material damage due to erroneous settings!

If the end position is approached too hard, the product may be damaged.

- Adjust exhaust throttle valve and shock absorber so that the movement is braked smoothly.

For operation, the angle of rotation, the swiveling speed and the absorber stroke must be set. For variants with pneumatic or locked center position, the center position must be set as well. Settings must always be made under the later operating conditions. If the operating conditions change, e.g., weight of the workpiece, check that the movement is braked smoothly. If necessary, readjust rotating angle, swiveling speed, absorber stroke and center position.

Angle of rotation

The angle of rotation is set in order to achieve a fine adjustment of the end positions.

The end positions can be configured by $\pm 3^\circ$. If the end positions are adjusted, the swiveling speed and absorber stroke might also have to be readjusted.

Swiveling speed and absorber stroke


Swiveling speed and absorber stroke are set in order to ensure a smooth operating cycle for the operating conditions, as both settings are dependent on each other.

Each end position is set separately. The position of exhaust throttle valve and shock absorber may deviate from one another.

Center position


The center position can be adjusted by $\pm 3^\circ$. If the center position is adjusted, the angle of rotation, swiveling speed and absorber stroke might also have to be readjusted.

Optimal setting




Swiveling speed and absorber stroke are optimal.


Erroneous setting



Swiveling speed too high. Assembly oscillates back.



Absorber stroke is too long. End position is reached too slowly.



Absorber stroke is too short. Assembly hits the end position.

5.4.1 Adjust swivel angle


CAUTION

Material damage due to incorrect settings!

By incorrect setting of the swivel angle parts can come loose and the product may be damaged.


- Only trained staff may set the swivel angle.
- Before setting the swivel angle release pressure.

Version with clamp shells



1. Loosen screw of the limiting sleeve (6) approx. one revolution.
2. Actuate air connection B (4).
3. Open exhaust throttle valve on air connection A (3) until the pinion (5) starts to move.
⇒ Pinion swivels towards the end position.
4. Set the desired end position by twisting the stop B (2).
5. Check end position.
⇒ To do this, ventilate air connection B (4) and actuate it again, if necessary adjust end position.
6. Tighten screw (6).
7. Loosen screw (7) by approx. one revolution.
8. Ventilate air connection B (4) and actuate air connection A (3).
9. Open exhaust throttle valve on air connection B (4) until the pinion (5) starts to move.
⇒ Pinion swivels towards the end position.
10. Set the desired end position by twisting the stop A (1).
11. Check end position.
⇒ To do this, ventilate air connection A (3) and actuate it again, if necessary adjust end position.
12. Tighten screw (7).
⇒ Tightening torque:SRU-plus-D 20-30: 1.2 Nm/ SRU-plus-D 35-50: 2.1 Nm
13. Swivel repeatedly to test the setting, adjust if necessary.

Version with limiting sleeve



1. Loosen screw of the limiting sleeve (6) approx. one revolution.
2. Actuate air connection B (4).

3. Open exhaust throttle valve on air connection A (3) until the pinion (5) starts to move.
 - ⇒ Pinion swivels towards the end position.
4. Set the desired end position by twisting the stop B (2).
5. Check end position.
 - ⇒ To do this, ventilate air connection B (4) and actuate it again, if necessary adjust end position.
6. Ventilate air connection B (4) and actuate air connection A (3).
7. Open exhaust throttle valve on air connection B (4) until the pinion (5) starts to move.
 - ⇒ Pinion swivels towards the end position.
8. Set the desired end position by twisting the stop A (1).
9. Check end position.
 - ⇒ To do this, ventilate air connection A (3) and actuate it again, if necessary adjust end position.
10. Tighten screw (6).
 - ⇒ Tightening torque:SRU-plus-D 20-40: 10 Nm/SRU-plus-D 50-60: 24 Nm
11. Swivel repeatedly to test the setting, adjust if necessary.


5.4.2 Adjust swiveling speed

CAUTION

Material damage due to too high swiveling speed!

If the swiveling speed is too high, the assembly will be decelerated abruptly by the shock absorber and will continue to oscillate until reaching the end position. This will overload the shock absorber and may cause damage to it.

- Adjust the swiveling speed in a way, that the movement decelerate smoothly in the end position.



1. Close both exhaust throttle valves completely.
2. **At the air connection A (3):**
3. Actuate air connection A (3).
4. Open exhaust throttle valve until the pinion (1) starts to move.
⇒ Pinion swivels towards the end position.
5. Continue to open the exhaust throttle valve incrementally until the movement brakes smoothly.
6. If the swivel speed is too high, the exhaust throttle valve must be closed again incrementally, until the optimal swivel time is reached.
7. Swivel repeatedly to test the setting, readjust if necessary.
8. **On the air connection B (2):**
Repeat the steps for the other end position.

NOTE

Further setting of the movement is carried out via the absorber stroke, ► 5.4.3 [39].

For the variants with pneumatic and locked center position, air supply throttle valves must be mounted to various air connections, ► 5.2.2 [29]. The sequence for setting the swivel speed with the air supply throttle valve is identical to the sequence with mounted exhaust throttle valve.

In addition to air connections A and B the air connections C and D must also be set for the variants with pneumatic and locked center position.

For the variant with locked center position and separate piston chambers, the air connections A1, A2, B1 and B2 must be set.

5.4.3 Adjust absorber stroke


CAUTION

Material damage to the product possible!

If the maximum adjustment range of the absorber stroke is exceeded, this can cause leaks in the product.

- When setting the absorber stroke, adhere to the maximum adjustment range.

SRU-plus-D	Max. adjustment range [mm]
20	7.5
25	7.5
30	7.5
35	6.5
40	6.5
50	10.5
60	10.5



1. Check deceleration of the movement in the end positions.
 - ⇒ If the absorber stroke is too long, the end position is reached too slowly.
 - ⇒ If the absorber stroke is too short, the assembly impacts in the end position.
2. **On the first shock absorber (1):** remove cover (5).
3. Fix back stop A (2) and loosen nut (3) on stop pin A (4).
4. Fix back stop A (2) and set stop pin A (4).

NOTE


If the absorber stroke is changed, the swivel speed might also need to be changed as well, so that the movement remains smooth, ► 5.4.2 [37].

- ⇒ **IMPORTANT! If the stop pin is unscrewed too far, this may cause the rotary actuator to leak.**
By unscrewing stop pin A (4), the absorber stroke is reduced.
- ⇒ By screwing in stop pin A (4), the absorber stroke is increased.
- 5.** Fix stop pin A (4) and tighten bolt (3).
- 6.** Fix back stop A (2) and tighten bolt (3).
- 7.** Swivel repeatedly to test the setting, set again if necessary.
⇒ The end positions must be approached gently.
- 8.** Put on cover cap (4).
- 9. On the second shock absorber (6)**
Repeat the steps for the other end position.

NOTE

Depending on the loading condition, the settings for the two shock absorbers may deviate widely from each other.

5.4.4 Set center position




- 1.** Loosen screw (1) by approx. one revolution.
- 2.** Unscrew stops C (2) and D (6) to the limit sleeve (4).
- 3.** Actuate air connections C (3) and D (5) at the same time.
⇒ Swivel unit pivots to about 90° and has about 6° of play in this position.

4. Turn pinion (7) clockwise and press and hold it to the stop C (2).
5. Turn stop C (2) to the required center position.
6. Turn stop D (6) until the pinion (7) no longer has play in the center position.
7. Tighten screw (1).
⇒ Tightening torque: 20–40: 10 Nm/ 50–60: 24 Nm
8. Swivel repeatedly to test the setting, readjust if necessary.

5.4.5 Set locked center position

Depending on the start-up direction of stop A (11) or stop B (10), the center positions can be set the same or differently.



1. Ventilate swivel unit.
2. Loosen screw (1) by approx. one revolution.
3. Actuate air connection B (2).
⇒ Swivel unit swivels to stop A (11).
4. Ventilate air connection B (2) and actuate air connection C (5).
⇒ Stop C (3) locks.
5. Actuate air connection A (4).
⇒ Swivel unit swivels to stop C (3), basic setting 90°.
6. Turn stop C (3) to the required center position.
7. Ventilate air connection C (5).
⇒ Swivel unit swivels to stop B (10).
8. Ventilate air connection A (4) and actuate air connection D (7).
⇒ Stop D (8) locks.
9. Actuate air connection B (2).
⇒ Swivel unit swivels to stop D (8).


10. Turn stop *D* (8) to the required center position.
11. Tighten screw (1).
⇒ Tightening torque: 20–40: 10 Nm/ 50–60: 24 Nm
12. Swivel repeatedly to test the setting, set again if necessary, ► 6.4 [46].

5.5 Mounting inductive proximity switch IN 80

With the sensors, three positions can be queried:

- End position "A"
- Center position "M"
- End position "B"


The following assembly steps are the same for all three positions:




1. Connect sensor and secure cable, see sensor assembly and operating manual.
2. Loosen screw (1, 2, 3).
3. Turn swivel unit counter-clockwise to the corresponding stop or the center position.
4. Insert sensor into the clamping sleeve (4) up to stop.
5. Unscrew clamping sleeve (4) until the sensor switches.
IMPORTANT! Risk of collision – Do not push the clamping sleeve too far into the bracket. Pay attention to the spacing between the clamping sleeve and the switching cam.
6. Tighten the screw (2, 3) until the clamping sleeve (4) can no longer be turned.
⇒ Screw (2, 3) jams the clamping sleeve (4) and at the same time secures the bracket (9, 10, 11).
7. Tighten the screw (1), until the sensor is fixed in place.
8. Check switching positions.

6 Start-up

6.1 Setting ranges of the variants



End position adjustability 3°



Variant angle of rotation 90°

6.2 Base unit

Move to basic setting 180° (end position B)

- Actuate air connection "A", pinion begins to move.
- ⇒ Assembly swivels in clockwise direction until it reaches the end position "B".

Move to basic setting 0° (end position A)

- Actuate air connection "B", pinion begins to move.
- ⇒ Assembly swivels until it reaches the end position "A".


6.3 Center position

NOTE

The center position can be adjusted by $\pm 3^\circ$. By design, overshooting can occur in the center position.

Move to basic setting 90° (center position)

- Actuate air connection "C" and "D" together, pinion begins to move.
- ⇒ Assembly swivels into center position.



Electrical circuit diagram actuation with one 5/3 and one 3/2 directional control valve, example

6.4 Locked center position



⚠ WARNING

Risk of injury due to unexpected movement of the machine/system!

In an EMERGENCY STOP situation, the center position lock can come loose.

- Swivel the product to one of the end positions to restart.

CAUTION

Damage due to erroneous control!

Erroneous control may damage the pistons.

- The locking pistons must be free to extend without striking the drive pistons.
- Observe electrical circuit diagram, electrical circuit diagram actuation with two 5/3 directional control valves (example).

If this option is selected, the locking pistons can stop the rotating motion in the center position and enable it again. The center position can be adjusted by $\pm 3^\circ$.

Move from 0° position to the center position


1. Extend locking piston "C".
 2. Actuate air connection "A", pinion begins to move.
- ⇒ Assembly swivels into center position.

Move from 180° position to the center position

1. Extend locking piston "D", pinion begins to move.
 2. Actuate air connection "B".
- ⇒ Assembly swivels into center position.

NOTE

Before actuating "C" and "D", connections "A and "B" must be completely ventilated. Observe the waiting period here, ► 6.4 [46].



Electrical circuit diagram actuation with two 5/3 directional control valves, example

6.5 Locked center position with separate piston chambers



⚠ WARNING

Risk of injury due to unexpected movement of the machine/system!

In an EMERGENCY STOP situation, the center position lock can come loose.

- Swivel the product to one of the end positions to restart.



⚠ WARNING

Risk of injury due to unexpected movement of the machine/system!


With a horizontal swiveling axis, secure locking is not guaranteed during the ventilation stage when a swivelling movement is being performed from 3 o'clock (180°) to 6 o'clock (90°) or from 9 o'clock (0°) to 6 o'clock (90°).

- Screw the separating sleeves into air connections "A" and "B".
- Control both piston chambers of the "A" and "B" air connections separately for the purpose of holding torque.

The piston chambers "A" and "B" are separated by one separating sleeve each into two independent piston chambers, "A1" and "A2" and "B1" and "B2". By using supply air throttle valves, piston chambers can be actuated separately.

Holding the load at 0°

1. Actuate air connection "B1", until the pinion begins to move.
 2. Ventilate air connection "B2".
 3. Actuate air connection "C".
 4. Observe waiting period, ▶ 6.5 [48].
 5. Ventilate air connection "B1".
 6. Actuate air connections "A1" and "A2".
- ⇒ Assembly swivels until locking of C.



Electrical circuit diagram holding the load at 0°

The following actuation is advantageous for variants from size 35 and larger depending on the application:

- A brief ventilation while the lock is being released ensures smooth travel to the limit position.
- Exhaust air throttle valves can be used for air connections "A1" and "B1" by installing separating sleeves. The air connections "A2" and "B2" then remain unthrottled.

7 Troubleshooting

7.1 Product does not move smoothly to the end positions

Possible cause	Corrective action
Dampening stroke shifted.	Adjust absorber stroke. ▶ 5.4.3 [39]
Shock absorber defective.	Check or, if need be, replace the shock absorber. ▶ 8 [51]

7.2 Product does not travel through the rotating angle

Possible cause	Corrective action
Accumulation of dirt between stop / sleeve and pistons.	Clean and lubricate product. ▶ 8 [51]
End positions are adjusted incorrectly.	Adjust end position. ▶ 5.4.1 [35]
Pressure drops below minimum.	Check air supply. ▶ 5.2.2 [29]
Components have come loose e.g. due to overloading.	Send product with a SCHUNK repair order or dismantle product.
Shock absorber defective.	Check or, if need be, replace the shock absorber. ▶ 8 [51]

7.3 Product rotates jerkily

Possible cause	Corrective action
Too little grease in the mechanical guiding areas.	Clean and lubricate product. ▶ 8 [51]
Compressed air lines blocked.	Check compressed air lines of damage.
Swiveling speed set too fast	Adjust swiveling speed ▶ 5.4.2 [37]

7.4 Product does not move

Possible cause	Corrective action
Component part defective.	Replace component or send it to SCHUNK for repair. Have Schunk check the application.
Pressure drops below minimum.	Check air supply. ▶ 5.2.2 [29]
Compressed air lines switched.	Check compressed air lines.

Possible cause	Corrective action
Unused air connections open.	Close unused air connections. ▶ 5.2.2 [29]
Both exhaust air throttle valves are closed.	Open one exhaust air throttle valve.
Proximity switch defective or set incorrect.	Adjust sensor or if necessary change sensor. ▶ 5.5 [42]

7.5 Torque is diminishing

Possible cause	Corrective action
Compressed air can escape.	Check seals, if necessary, disassemble the product and replace seals. ▶ 8.6 [59]
Too much grease in the mechanical movement space.	Clean and lubricate product. ▶ 8 [51]
Pressure drops below minimum.	Check air supply. ▶ 5.2.2 [29]

8 Maintenance

8.1 Maintenance interval

CAUTION

Material damage due to hardening lubricants!

Lubricants harden more quickly at temperatures above 60°C, leading to possible product damage.

- Reduce the lubricant intervals accordingly.

All sizes

Interval	Maintenance work
daily	Visually inspect the function of the shock absorbers, ► 8.3.1 [53].

SRU-plus-D 20 – 40

Interval [Mio. cycles]	Maintenance work
2	Clean all parts thoroughly, check for damage and wear, if necessary replace seals and wearing parts, ► 8.6 [59].
2	Treat all grease areas with lubricant, ► 8.2 [52].
2	Check that the shock absorbers are working, if necessary replace shock absorber, ► 8.5 [56].

SRU-plus-D 50 – 60

Interval [Mio. cycles]	Maintenance work
1	Clean all parts thoroughly, check for damage and wear, if necessary replace seals and wearing parts, ► 8.6 [59].
1	Treat all grease areas with lubricant, ► 8.2 [52].
1	Check that the shock absorbers are working, if necessary replace shock absorber, ► 8.5 [56].

8.2 Lubricants/Lubrication points (basic lubrication)



⚠ WARNING

Risk of injury due to contact with lubricants!

Lubricant may cause irritation and allergic reactions if it contacts the skin or eyes.

- Avoid contact between lubricant and skin or eyes.
- Wear safety goggles and protective gloves.
- Observe information on the safety data sheet of the lubricant.

During maintenance, treat all greased areas with lubricant. Thinly apply lubricant with a lint-free cloth.

SCHUNK recommends the lubricants listed.

Lubricant point	Lubricant
The teeth and the pinion	Rivolta F.L.G. GT-2
All seals	Rivolta F.L.G. GT-2

The product contains food-compliant lubricants as standard. Components such as rolling bearings, linear guides, or shock absorbers are not provided with food-compliant lubricants.

The requirements of standard EN 1672-2:2020 are not fully met.

NOTE

- Change contaminated food-compliant lubricant.
- Observe information in the safety data sheet from the lubricant manufacturer.

8.3 Inspect and set shock absorbers


8.3.1 Inspect shock absorbers

The shock absorbers are specially tested and can only be acquired from SCHUNK. The shock absorbers have a limited lifespan, depending on the load.

- Regularly check that the shock absorbers are working.
 - ⇒ The shock absorber is working correctly if the product moves softly into the end positions when set correctly and the prescribed swiveling time is reached.

8.3.2 Set shock absorber overhang

For production reasons, shock absorbers may be of different sizes. If a shock absorber is exchanged, the new shock absorber with fitting disks must be set to the corresponding shock absorber overhang (h).




1. First set the shock absorber overhang (h) of the shock absorber (2) in the piston (1) with fitting disks (5) ► 8.3.3 [54].
2. After this, reduce the play of the shock absorber (2) to the safety ring (3) with fitting disks (4).
 - ⇒ The shock absorber (2) must be fitted in the pistons (1) as free from play as possible.

8.3.3 Shock absorber types and overlap

Type	Basic			Locked center position		
	Shock absorber	Shock absorber overlap h [mm]	Tolerance [mm]	Shock absorber	Shock absorber overlap h [mm]	Tolerance [mm]
20 W	FED 14	4.6 (without spring)	-0.2	---	---	---
20 W VM	FED 14	4.6 (without spring)	-0.2	WP-M 0.25-356	9.5	± 0.05
25 W	WP-M 0.4-266	14	-0.1	---	---	---
25 W VM	WP-M 0.4-266 VM	10	-0.1	WP-M 0.4-266 G	14	-0.1
30 W	WP-M 0.6-466	19.5	-0.1	---	---	---
30 W VM	WP-M 0.6-566 VM	12	-0.1	WP-M 0.6-466 G	19	-0.1
35 W	WP-M 0.6-366	19.5	-0.1	---	---	---
35 W VM	WP-M 0.6-466 VM	17.2	-0.1	WP-M 0.6-366 G	19	-0.1
40 W	WP-M 1.0-266	Place fitting disks on shock absorber until it sits in the piston free from play, ► 8.3.2 [53].		---	---	---
40 W VM	WP-M 1.0-266	19.4	-0.1	WP-M 1.0-266 G	22	-0.1
50 W	WP-M 1.0-266	Place fitting disks on shock absorber until it sits in the piston free from play, ► 8.3.2 [53].		---	---	---
50 W VM	WP-M 1.0-266	20.4	-0.1	WP-M 1.0-266 G	22	-0.1
60 W	WP-M 1.25x2-266	Place fitting disks on shock absorber until it sits in the piston free from play, ► 8.3.2 [53].		---	---	---
60 W VM	WP-M 1.25x2-266 VM			WP-M 1.0-266 G	23	-0.1


8.4 Servicing shock absorber



1. Undo the screws (1).
2. Pull off the stop cover (2).
3. Remove the safety ring (4) from the piston.
4. Pull out the piston rod (3) and remove the compression spring (5).
5. Pull out the piston (7) with the guide sleeve (6) and dampening ring (8).
6. Replace dampening ring (8).
7. Insert the piston (7) with the guide sleeve (6) and dampening ring (8) using the piston rod (3) as far as possible.
8. Check the shock absorber overlap (h),
 ▶ 8.3.3 [54].
 ⇒ If necessary, add or remove fitting disks on base side until the required absorber overlap (h) is reached.
9. Remove the piston rod (3).
10. Grease and insert the compression spring (5).
11. Grease the piston rod (3) inside and outside and insert it.
12. Mount the safety ring (4).
 ⇒ Pay attention to the correct installation position of the safety ring.
13. Mount the stop cover (2) with screws (1).


8.5 Replace shock absorber

8.5.1 Replace shock absorber (base unit)



1. Ventilate rotary actuator.
2. Unscrew screws (6).
3. Turn pinion (2) to end position.
4. Remove stop cover (7).
5. Remove safety ring (5) on piston (3).
6. Pull out shock absorber (4) with fitting disks.
7. Insert new shock absorbers.
8. Set shock absorber overhang (h),
▶ 8.3.2 [53].
9. Set safety ring (5) in the groove of the piston.
10. Turn pinion (2) to end position.
⇒ Piston (3) is retracted into the housing (1).
11. Screw on stop cover (7) again.
12. Proceed analogously for the second shock absorber.
13. If necessary, adjust the shock absorber, ▶ 5.4 [33].

8.5.2 Replacing external shock absorber (locked center position)



1. Fix stop (1) and unscrew the sealing nut (4) of the shock absorber (3).
2. Turn shock absorber (3) out of the stop (1).
3. Mount O-ring (2) on new shock absorber.
4. Screw sealing nut (4) onto the shock absorber (3)
5. Screw in new shock absorber as far as possible.
6. Adjust absorber stroke, ► 5.4.3 [39].
7. Fix stop (1) and tighten the sealing nut (4) of the shock absorber (3).
8. Swivel repeatedly to test the setting, if necessary set again, ► Electrical circuit diagram actuation with two 5/3 directional control valves (example) [46].

8.5.3 Replace internal shock absorber (locked center position)




⚠ WARNING

Risk of injury due to spring forces!

In the interior of the centering housing (locked center position variant), a pre-loaded compression spring can be found.


- Carefully dismantle the product.



1. Unscrew screw (5) on stops C and D (4) one turn.
2. Unscrew bolt (3) of the limiting sleeve.
3. Unscrew stops C and D (8) and in doing so retighten screw (3) until the centering housing (6) can be removed.
 - ⇒ Unscrew both stops (4) evenly in order to prevent the centering housing (6) from tilting.
4. Remove the safety ring (7) on piston (2).
5. Pull out shock absorbers (8).
6. **IMPORTANT! Carefully mount shock absorber in order to avoid damage to the O-rings.**
Insert new shock absorbers.
 - ⇒ Pay attention to the shock absorber overhang,
Shock absorber types and shock absorber overlap (h).
7. Mount the safety ring (7).
8. Press stops C and D into the centering housing (6) until they are flush with the centering housing (6).
9. Fit centering housing (6) to the base unit (1) and slightly tighten the stops C and D.
10. Slightly tighten screw (3).
11. Press centering housing (6) onto the base unit (1) and evenly tighten the stops C and D as well as the screw (5).
12. Tighten screw (3) and then loosen approx. 1/4 revolution.
13. Swivel repeatedly to test the setting, if necessary readjust ► [Electrical circuit diagram actuation with two 5/3 directional control valves \(example\)](#) [46].


8.6 Disassembly and assembly

8.6.1 Dismantling and assembling rotary actuator (base unit)




1. Ventilate rotary actuator.
2. Remove all air connections, ► 5.2.2 [29].
3. Dismantle sensors if necessary.
4. Unscrew screws (8),(9) and remove clamp shell (10), then remove both stop covers (7).
5. Remove curved cover (3).
6. Mark the installation position of the pinion (1) and the pistons (4).
7. Unscrew protective cover (5).
8. Remove safety ring (6) on pinion (1).
9. Take pinion (1) out of the housing (2).
10. Take both pistons (4) out of the housing (2).
11. Assemble rotary actuator in the reverse order.
 - ⇒ Unless otherwise specified, secure all screws and nuts with Loctite no. 243 and tighten with the appropriate tightening torque.

8.6.2 Dismantle and assemble rotary actuator (center position/ locked center position)



- 1.** Ventilate rotary actuator.
- 2.** Remove all air connections, ► 5.2.2 [29].
- 3.** Dismantle sensors if necessary.
- 4.** Unscrew screws (10) and remove both stop covers (9).
- 5.** Unscrew screw (4) on stops "C" and "D" (5) one turn.
- 6.** Unscrew screw (3) of the limiting sleeve.
- 7.** Unscrew stops "C" and "D" (5) and in doing so retighten screw (4) until the centering housing (2) can be removed.
⇒ Unscrew both stops (5) evenly in order to prevent the centering housing (2) from tilting.
- 8.** Mark the installation position of the pinion (1) and the pistons (6).
- 9.** Unscrew protective cover (7).
- 10.** Remove safety ring (8) on pinion (1).
- 11.** Take pinion (1) out of the housing (11).
- 12.** Take both pistons (6) out of the housing (11).
- 13.** Assemble rotary actuator in the reverse order.
⇒ Unless otherwise specified, secure all screws and nuts with Loctite no. 243 and tighten with the appropriate tightening torque.

8.6.3 Dismantling and assembling rotary actuator (fluid feed-through)



1. Ventilate rotary actuator.
2. Remove all air connections, ► 5.2.2 [29].
3. Dismantle sensors if necessary.
4. Unscrew screws (7) and (11), remove clamp shell (10) and both stop cover (8).
5. Mark the installation position of the pinion (1) and the pistons (2).
6. Unscrew screws (6).
7. Remove flange (5).
8. Remove safety ring (4) on pinion (1).
9. Take pinion (1) out of the housing (9).
10. Take both pistons (2) out of the housing (9).
11. Assemble rotary actuator in the reverse order.
 - ⇒ Unless otherwise specified, secure all screws and nuts with Loctite no. 243 and tighten with the appropriate tightening torque.

9 UKCA declaration of incorporation

in accordance with the Supply of Machinery (Safety) Regulations 2008.

Manufacturer/	SCHUNK Intec Limited
Distributor	Clamping and gripping technology
	3 Drakes Mews, Crownhill
	MK8 0ER Milton Keynes

We hereby declare that on the date of the declaration the following partly completed machine complied with all basic safety and health regulations found in the "Supply of Machinery (Safety) Regulations 2008".

The declaration shall be rendered invalid if modifications are made to the product.

Product designation: Pneumatic swivel unit / SRU-plus-D / pneumatic

The partly completed machine may not be put into operation until it has been confirmed that the machine into which the partly completed machine is to be installed complies with the provisions of the "Supply of Machinery (Safety) Regulations 2008".

Applied harmonized standards, especially:

EN ISO 12100:2010	Safety of machinery – General principles for design – Risk assessment and risk reduction
-------------------	---

The special technical documentation according to Annex VII, Part B, belonging to the partly completed machine, has been created.

Person authorized to compile the technical documentation:
Marcel Machado, address: refer to manufacturer's address



Lauffen/Neckar, October 2023

Dr.-Ing. Manuel Baumeister,
Head of Systems Engineering,
Technology & Innovation

10 Translation of the original declaration of incorporation

in terms of the Directive 2006/42/EG, Annex II, Part 1 Section B.

Manufacturer/	SCHUNK SE & Co. KG
Distributor	Toolholding and Workholding Gripping Technology Automation Technology
	Bahnhofstr. 106 – 134
	D-74348 Lauffen/Neckar

We hereby declare that the partly completed machine described below

Product designation:	Pneumatic swivel unit / SRU-plus-D /pneumatic
ID number	37361402 ... 37362802, 1001682 ... 1001722

meets the following basic occupational health and safety of the Machinery Directive 2006/42/EC:

No. 1.1.1, No. 1.1.2, No. 1.1.3, No. 1.1.5, No. 1.3.2, No. 1.5.3, No. 1.5.4, No. 1.5.6, No. 1.5.8, No. 1.5.10, No. 1.5.11, No. 1.5.13

The partly completed machinery may not be put into operation until it has been confirmed that the machine into which the partly completed machinery is to be installed complies with the provisions of the Machinery Directive (2006/42/EC). The declaration shall be rendered invalid if modifications are made to the product.

Applied harmonized standards, especially:

EN ISO 12100:2010	Safety of machinery – General principles for design – Risk assessment and risk reduction
-------------------	--

The special technical documentation according to Annex VII, Part B, belonging to the partly completed machine, has been created.

Person authorized to compile the technical documentation:
Stefanie Walter, Address: see manufacturer's address

Signature: see original declaration

Lauffen/Neckar, October 2023

Dr.-Ing. Manuel Baumeister,
Head of Systems Engineering,
Technology & Innovation

11 UKCA declaration of incorporation

in accordance with the Supply of Machinery (Safety) Regulations 2008.

Manufacturer/	SCHUNK Intec Limited
Distributor	Clamping and gripping technology 3 Drakes Mews, Crownhill MK8 0ER Milton Keynes

We hereby declare that on the date of the declaration the following partly completed machine complied with all basic safety and health regulations found in the "Supply of Machinery (Safety) Regulations 2008".

The declaration shall be rendered invalid if modifications are made to the product.

Product designation:	Pneumatic swivel unit / SRU-plus-D / pneumatic
ID number	37361402 ... 37362802, 1001682 ... 1001722

The partly completed machine may not be put into operation until it has been confirmed that the machine into which the partly completed machine is to be installed complies with the provisions of the "Supply of Machinery (Safety) Regulations 2008".

Applied harmonized standards, especially:

EN ISO 12100:2010	Safety of machinery – General principles for design – Risk assessment and risk reduction
-------------------	---

The special technical documentation according to Annex VII, Part B, belonging to the partly completed machine, has been created.

Person authorized to compile the technical documentation:
Marcel Machado, address: refer to manufacturer's address



Lauffen/Neckar, October 2023

Dr.-Ing. Manuel Baumeister,
Head of Systems Engineering,
Technology & Innovation

12 Information on the RoHS Directive, REACH Regulation and Substances of Very High Concern (SVHC)

RoHS Directive

SCHUNK products are classified as "large-scale stationary installations" or as "large-scale stationary industrial tools" within the meaning of Directive 2011/65/EU and its extension 2015/863/EU "on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS)", or fulfill their intended function only as part of one. Therefore products from SCHUNK do not fall within the scope of the directive at this time.

REACH Regulation


Products from SCHUNK fully comply with the regulations of Regulation (EC) No. 1907/2006 "concerning the Registration, Evaluation, Authorization and Restriction of Chemicals (REACH)" and its amendment 2022/477. SCHUNK attaches great importance to completely avoiding chemicals of concern to humans and the environment wherever possible.

Only in rare exceptional cases do SCHUNK products contain SVHC substances on the candidate list with a mass content above 0.1%. In accordance with Article. 33 (1) of Regulation (EC) No. 1907/2006, SCHUNK complies with its duty to "communicate information on substances in articles" and lists the components concerned and the substances used in an overview that can be viewed at schunk.com/SVHC.

Signature: see original declaration

Lauffen/Neckar, October 2023

Dr.-Ing. Manuel Baumeister,
Head of Systems Engineering,
Technology & Innovation







SCHUNK SE & Co. KG
Toolholding and Workholding | Gripping Technology |
Automation Technology

Bahnhofstr. 106 – 134
D-74348 Lauffen/Neckar
Tel. +49-7133-103-0
info@de.schunk.com
schunk.com

Folgen Sie uns | *Follow us*



Wir drucken nachhaltig | *We print sustainable*